



Notes:

1. The EcoFlex-F membrane extending over the parapet exterior is for waterproofing only.
2. EcoFlex-S is self-sealing when self-taping fastening systems are used.
3. Air barriers should be continuously supported throughout the building envelope. Use galvanized sheet metal, exterior sheathing or other method to provide support around the perimeter of steel deck assemblies.