



Notes:

1. EcoFlex-F self-adhering sheets are used for thru-wall flashing applications. EcoFlex-F is applied to a prepared and primed substrate.
2. Integrate the wall air/vapor barrier system with foundation waterproofing or dampproofing system.
3. When the brick-tie system is installed prior to the EcoFlex-F membrane, cut and fit the membrane around each tie and seal with EcoFlex-S or R.
4. An alternate detail for the thru-wall flashings includes extending the membrane across the top of the floor slab prior to installing the lower track. Turn membrane up face of track prior to fastening interior gypsum board./

FOUNDATION DETAIL

eeproTM
Waterproofing Systems



AB-3