



Notes:

1. EcoFlex-F is a self-adhering sheet used for thru-wall flashing applications. EcoFlex-F is applied to a prepared and primed substrate.
2. Always stop EcoFlex-F membrane flashing back from exterior face of veneer. Extend the drip edge using prepainted metal to suit.
3. Apply EcoFlex-S or R to back of insulation panels in a serpentine pattern, and to insulation panel joints, to restrict air movement.

SHELF ANGLE DETAIL



AB-4