



The tie-in detail for the exterior sides of the "C" channel is the same as the interior soldier beam.

- A. Apply a 30-mil coat of Ecoline to the interior sides of the "C" channel.
- B. Install Ecodrain-DS 6", dimple side out. Wedge tight back into channel against soil or (mechanically fastens if necessary).
- C. Apply a 30-mil at coat of Ecoline-R to the transition of Ecodrain-DS 6" and the "C" channel.
- D. Install 12" polyester strip over the Ecodrain-DS extending 3" on each side of the "C" channel.
- E. Apply 80-mil coat of Ecoline-S over the polyester strip and interior sides of the "C" channel.

"C" CHANNEL
DETAIL

epro™
Waterproofing Systems



LW-12